

**MANUAL INSTRUCTIONS
FOR
ULTRASONIC HUMIDIFIER
MODEL FYB-58**

**WARNING!!
THIS HUMIDIFIER IS NOT
A TOY
DO NOT LET CHILDREN
PLAY WITH IT!!**

PLEASE READ THE INSTRUCTIONS TO ENSURE
SAFE USE OF THIS HUMIDIFIER

WARNING!

READ THESE INSTRUCTIONS.

Failure to follow the instructions may result in fire, electric shock and/or serious injury.

1. This humidifier is intended only for indoor use.
2. Use only clean water. Do not use hot water.
3. It is recommended to use filtered or distilled water.
4. Make sure that cap of tank is tightened firmly.
5. The mist direction should be aimed away from walls, electric appliances, furniture and children.
6. Do not force the Mist Nozzle to a certain angle. To adjust the angle, resettle it.
7. Place the humidifier on a flat, smooth, level surface.
8. Do not plug and unplug humidifier with wet hands.
9. Use only a 220-240 Volt , 50/60Hz outlet.
10. Unplug the humidifier when moving or cleaning it.
11. Unplug the humidifier when not in use.
12. Do not attempt to empty, fill, and tilt the humidifier while it is working.

SAFETY WARNINGS

1. Place the humidifier on a stable surface.
2. Do not immerse humidifier in water.
3. Do not place the humidifier close to a heat source.
4. Do not pull the plug from socket by the cord.
5. Unplug the humidifier immediately if it appears to be faulty.
6. Unplug the humidifier while not using it.
7. Before cleaning make sure the plug is not in the wall socket.
8. While filling the humidifier with water or emptying it, it must be unplugged.

OPERATING INSTRUCTIONS

1. Place humidifier on an elevated waterproof surface. Do not place humidifier on a towel or a carpeted surface. The vent for the fan on the bottom may become blocked and cause the humidifier to overheat.
2. Remove the Spout from Ax on top of Humidifier
3. Lift the water tank by the handle off the body, turn it over and unscrew the water tank cap.
4. Fill the tank with cold water but not all the way to the rim.
5. Screw the cap back on, turn the water tank over and place it on the body.
6. Put the Spout back onto the Ax, so that it will not revolve only by the motor.
7. Plug the cord into a wall socket and push the Power Button in, to turn the humidifier on.
8. After a few seconds mist will start emitting out of the Spout.
9. To adjust the intensity of the mist outputs, turn the Mist Adjusting Button to your requirements. **(It is normal to hear a dripping sound when mist output is at a high level).**
10. As a safety feature, the Water Deficiency Indicator Light will illuminate and the mist output will stop immediately after the humidifier runs out of water.
11. By pressing the Revolving Mode Button in, the Mist Spout will revolve at 360° angle. For a longer engine life, after continuous use of the revolving feature for 10 hours, please wait about 2 hours before using the revolving system again.

CLEANING & MAINTENANCE

SWITCH THE HUMIDIFIER OFF AND UNPLUG IT BEFORE CLEANING

1. The exterior of the unit should be cleaned by wiping it with a soft dry cloth.
2. The inside of the tank should be cleaned once a week, as follows; Fill the water tank with clean water, add a few drops of bleach, then shake it for a few seconds. Shake it holding it with both hands. Do not hold it by the handle. After shaking, spill the water and then rinse the unit thoroughly.
3. Do not clean with any chemicals.
4. Avoid water from entering into the body.
5. Clean sensitive parts with water mixed with vinegar on a soft cloth.

STORING

1. Before storing, the humidifier must be cleaned and drained.
2. When storing the unit, make sure that all parts are dry.
3. Do not close the water tank cap too tight. Leave it loose, so it should not stick to the gasket.
4. Do not put anything on top of the unit during storage, to prevent any damage to it.
5. Save the box and store the unit in the box.

TROUBLE SHOOTING

DO NOT ATTEMPT TO REPAIR THE HUMIDIFIER YOURSELF

Problem	Solution
Power Indicator Light is not turning on.	Ensure that there is water in tank and everything is assembled properly.
Humidifier does not work at all.	Make sure it is properly plugged into outlet and Power Button is in ON position.
The Power Indicator light is on but no mist or very little is being emitted.	Make sure that nothing blocks the mist Spout nozzle. Check if there is water in the tank. Make sure that the fan vent on the bottom is not blocked.
White dust appears outside the humidifier.	The water you are using might have too many minerals. Change to distilled or filtered water.
If there is a strange odor.	Clean the water tank. Leave the tank open without the cap for some time.

SPECIFICATIONS

Model	FYB-58/FYB-62
Voltage	220-240V 50/60Hz
Power	23W
Capacity	2.5L